


How to use..... Olympus Digital Recorder (VN-6800PC)



Turning On the Power

Slide the **HOLD** switch in the direction opposite that indicated by the arrow.


The display will turn on and the power will be turned on. The resume function will bring the recorder back to the stop position in memory before power was turned off.



Turning Off the Power

Slide the **HOLD** switch in the direction indicated by the arrow while the recorder is not in operation.

The display shuts off and the power will be turned off. The resume function remembers the stop position before the power is turned off.




- **How to select a folder and record**

1. Press the 'folder' button to choose a folder in which to make a recording.
2. Press the 'rec' button to start recording. The record/play indicator light glows red.
3. Press the 'stop' button to stop recording.

- **Connecting to your PC**

1. With the recorder stopped, slide the 'hold' switch to the 'hold' position, and turn the recorder off – the display will turn off.
2. Connect the USB connector to a PC and recording device. Remote is displayed on the recorder if the USB is connected.
3. Launch My Computer, in the window, the recorder will appear as a removable disk.
4. Transfer the voice files to your computer and copy to file.

- **Disconnecting from your PC**

1. Click the  on the task bar located at the lower-right corner of the screen. Click 'safely remove hardware'.
2. When the safe to remove hardware window appears, click (ok)
3. Make sure that the display is turned off, and disconnect the USB.

Notes

- NEVER disconnect the USB while record/play indicator light and USB access indicator light are flashing red. IF you do so, the data may be destroyed.

Erasing

1. In the stop status, display the file or place the cursor on the file in the list display. Select the file you want to delete.
2. Press the 'erase' button. Press the » button to choose 'erase'
3. Press the OK button. The display changes to 'file erase' and erasing will start. Erase done is displayed when the file is erased.